



# GUIA DE REFERENCIAS DE SENSORES TIPO POSICIÓN CIGUEÑAL



# SENSORES TIPO POS

**33220-70E00**

SENSOR POS. CIQUENAL CHEV.ESTEM 1.3/1.6



**90451442**

SENSOR POS.CIGUENAL CHEV. CORSA



**96253542**

SENSOR POS.CIGUENAL CHEV.AVEO/OPTRA 1.4



**96325868**

SENSOR POS.CIGUENAL CHEV.SPARK M200 06/



**96418382**

SENSOR POS.CIGUENAL CHEV/DAE/ OPTRA 1.8



**39180-22600**

SENSOR POS.CIGUENAL HYU.ACCEENT/  
GETZ/ELAN



# SENSORES TIPO POS

**39180-247000**

SENSOR POS.CIGUENAL HYU.STA.FE/2.0 DIESEL



**39180-37150**

SENSOR POS. CIGUENAL HYU. STA.FE 2.7



**39310-02600**

SENSOR POS. CIGUENAL HYU. ATOS



**39310-38070**

SENSOR POS. CIGUENAL HYU. STA.FE 2.4



**8-97258-523-0**

SENSOR POS.CIGUENAL ISU.DMAX 3.5



**90919-05025**

SENSOR POS. CIGUENAL TOY.HILUX 1KD/2KDFT



# SENSORES TIPO POS

**90919-05030**

SENSOR POS. CIQUELAL TOY. 1ZZFE/3ZZFE



**90919-05045**

SENSOR POS. CIQUELAL TOY. YARIS 1NZ/2NZFE



**90919-05059**

SENSOR POS. CIQUELAL TOY. HILUX 1TR/2TRFE



**90919-05060**

SENSOR POS. CIQUELAL TOY. HILUX 1GRFE 08/

